



INSTRUCTIONS

1. MOUNTING ITEM TO ADAPTER


THERE ARE TWO METHODS FOR USING THE CABLE-TIES TO MOUNT THE ITEMS TO THE ADAPTERS: LOOPING AROUND (*METHOD A*) OR OVER THE TOP (*METHOD B*). LOOPING AROUND IS EASIEST, AND GOING OVER THE TOP WORKS BEST FOR SMALLER ITEMS. SEE ILLUSTRATION FOR DETAILS. ONCE THE ITEM IS IN THE CORRECT POSITION, PULL CABLE-TIES TIGHT AND USE A SCISSORS TO REMOVE THE EXCESS MATERIAL. TWO OR THREE CABLE-TIES ARE SUFFICIENT FOR ATTACHING MOST ITEMS. BE SURE THE ITEM DOES NOT EXTEND PAST THE REAR OF THE ADAPTER, OTHERWISE THE ITEM WILL NOT ATTACH TO THE ARM BRACE.



METHOD A



METHOD B



2. MOUNTING ARM BRACE

PLACE ARM BRACE ON ARM BY LOOSENING VELCRO STRAPS AND SLIDING ARM THROUGH OPENING OF LOOP. PLACE FRONT REST IN PALM OF HAND SO THAT THE FRONT STRAP CAN BE SECURED BEHIND THE


KNUCKLES. TIGHTEN REAR STRAP AROUND FOREARM. FOREARM CRADLE CAN BE SQUEEZED TOGETHER FOR SMALLER ARMS, OR EXPANDED FOR LARGER ARMS.

ALWAYS CHECK SKIN FOR REDNESS NEAR THE STRAPS AND OTHER CONTACT AREAS. THIS IS ESPECIALLY IMPORTANT FOR THOSE WITH REDUCED SENSATION.




3. MOUNTING ADAPTER TO ARM BRACE

SWING LOCKING BAR OPEN. PLACE HOOK END OF ADAPTER INTO SLOT NEAR THE REAR OF THE ARM BRACE. ROTATE ADAPTER SO THE LOCKING GROOVE PROTRUSION SLIDES INTO CHANNEL NEAR THE FRONT OF THE ARM BRACE. SWING LOCKING BAR SO ADAPTER IS LOCKED ONTO THE ARM BRACE. TO REMOVE ADAPTER SIMPLY SWING OPEN THE LOCKING BAR AND REVERSE ROTATION OF ADAPTER.



4. CHANGING DIRECTION OF LOCKING BAR (ONLY REQUIRED IF YOU WANT THE LOCKING BAR TO PIVOT FROM THE OTHER SIDE)

USE A 5/64" ALLEN-WRENCH TO REMOVE THE SET-SCREW THAT CONNECTS THE LOCKING BAR TO THE ARM BRACE. MOVE THE LOCKING BAR SO THE HOLE IN EITHER END LINES UP WITH THE OTHER PIVOT LOCATION ON THE ARM BRACE AND INSTALL SET-SCREW. (SEE ILLUSTRATION)



5. INSTALLING FOAM PAD (ONLY REQUIRED FOR SMALLER ARMS OR IF ADDITIONAL COMFORT IS REQUIRED)

PEEL ADHESIVE BACKING FROM FOAM. BEGIN BY ALIGNING FOAM WITH THE BOTTOM AND REAR-MOST PORTION OF THE ARM BRACE. PREVENT FOAM FROM STICKING TO THE SIDES OF THE CRADLE. PRESS FOAM ONTO CRADLE BY STARTING FROM THE CENTER AND WORK TOWARDS THE SIDES. PAY CAREFUL ATTENTION TO PRESSING THE FOAM INTO THE CORNERS BEFORE PRESSING IT TO THE SIDES. TRIM EXCESS FOAM AS DESIRED.